Swisscom blue TV Host

English

More than 300 TV channels from all over the world



Navigation buttons

Navigating via the menu / Info channel: **ring**
Press to confirm: **OK**
Return to previous step – briefly press once: ↖ **Back**
Return to the current programme – press once and hold: ↖ **Back**

Voice commands

You can dictate search terms. The microphone is only active while you are pressing the button. Hold the remote control about 30 cm from your mouth and the say the search term.
Speak into the microphone normally.
> Press and **hold** the 🎙 button on the remote control
> Say your search term clearly
> Release the 🎙 button again

New spoken commands are constantly being added to the ones already supported. www.swisscom.ch/smartremote

Changing channels

Switching between the last two channels – briefly press once: ⧉
Call up a list of the last watched content – press and hold once: ⧉
Switching between channels: ⇕

Teletext

Radio

Extra

Discover something bigger than Teletext – HbbTV, interactive TV.

On / off

Sound off

Select language

Select your desired language from the start screen at the top.

TV Guide

Here you'll find an overview of the TV programmes. You can see what's on TV where and when.

Option

This button provides you with useful information, viewing and filter options, for example select second language, subtitles or channel list – give it a try!

Channel lists

Up to five channel lists are available.

A different channel list can easily be selected using the Option button: > **Option** > **Change channel list**

Info channel (Hotel information)

Close info channel (back to live TV): press ⌂ Taste
If an info channel is available, press ⓘ in the top left-hand corner of the screen to select it.

Inhouse channel (Hotel live broadcasts)

The in-house channel can be found on channel _____.

Help

My television is on, but the TV-Box isn't? > Press the Vol button
The TV-Box is on, but my television isn't. > Press the ⏻ button and the Vol button

KKD+JM (B2C-TSP-UID) 11039486 08/2020 EN